

- (1) 22-170 Teddy & the Bear (1907), 101/2" long. Teddy fires a penny into the tree and a big, fierce bear pops out.
- (2) 22-000 Royal Elephant, 81/2" long. Elephant deposits your coin in his seat.
- (3) 22-180 Uncle Sam (1886), 11 4" high. Watch Uncle Sam waggle his whiskers and drop your coin into his bag.
- (4) 22-300 Humpty Dumpty (1880), 71/2" high. Place coin in clown's hand and he'll swallow it and roll his eyes.
- (5) 22-130 Paddy & the Pig (1882), 74" high. Pig kicks coin, Paddy swallows it and rolls his eyes.
- (6) 22-270 Hometown Battery (1888), 9¾" long. Pitcher tosses coin to the catcher, batter swings and misses so penny goes into bank through catcher.
- (7) 22-250 Kicking Cow (1888), 94" long. Cow kicks over milker and pail while coin drops inside bank.
- (8) 22-060 Santa Claus, 6" high. Santa throws coin down the chimney.
- (9) 22-335 Golfer Bank, 9" long. The old pro putts coin as caddie raises flag.
- (10) 22-280 Dentist (1880), 91/2" long. As dentist pulls tooth, coin falls from his pocket into gas bag.
- (11) 22-020 Kicking Mule (1879), 10" long. Mule throws jockey and coin in jockey's mouth goes through slot in base.