

22-190 William Tell. William fires pennies into bank which makes a bell ring. (Original produced 1896.) 10 1/4" long.



22-070 Indian & Bear. Load the Indian's gun with a coin. He'll fire it into the bear which snaps its jaws. (Original produced 1888.) 10 1/2" long.



22-030 Artillery. Cannon goes off at gunner's signal and shoots the penny into the fort. (Original produced 1892.) 8" long.



22-180 Uncle Sam. Push the lever and watch Uncle Sam waggle his whiskers and drop your penny into his carpetbag. (Original produced 1886.) 11 1/4" high.



22-260 Creedmore. Named for a National Guard rifle range on Long Island. Man shoots penny to target. (Original produced 1877.) 10" long.



22-230 U.S. Cannon. This bank commemorates Spanish-American War. Cannon brings down ship's mast and your coin. (Original produced 1898.) 8 3/4" long.



22-170 Teddy & the Bear. Rough Rider fires a penny into the tree, and a big, fierce bear pops out. (Original produced 1907.) 10 1/2" long.



Not a novelty but clever all the same. Mechanical banks sell today for the same reasons they did 100 years ago. The imaginative design, the ingenuity of the working parts, and the painstaking craftsmanship.

Click! Ker-plink! One try turns the curious browser into a delighted customer with cash in his hand and a remarkable gift under his arm.



22-000 Royal Elephant. Pull his tail and the elephant deposits your penny in the seat on his back. 8 3/4" long.



22-050 Eagle. Mother eagle feeds your penny to baby eagles. (Original produced 1883.) 8" long.



22-130 Paddy & the Pig. The pig kicks your penny to Paddy who catches it on his tongue, swallows it and rolls his eyes. (Original produced 1882.) 7 3/4" high.



22-200 World's Fair. An iron craftsman first produced this bank to commemorate Columbus' landing. And he displayed it at the Columbian Exposition. The Indian rises out of the ground, and your penny rolls between Columbus' feet into the bank. 8" long.